



**ORDER BY PART NUMBER, NOT CODE NUMBER**

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	11004	1	Flange, Mounting	28	13369	4	Screw (1/4-20x3/4)
2	11016	1	Gasket, Mounting	29	13675-D	1	Rotor & Shaft Assy (Incl. Code 43)
3	11024-A	1	Body, Assy, Upper	30	12426	1	Trim, Band
4	1491	6	Screw (1/4-20x3/4)	31	1836-A	2	Screw (8-32x1/2)
5	11227	1	Pipe, Plug	32	13714-E	1	Stator Assy
6	11006	1	Gasket, Shredder	33	12433-E	1	Bracket Assy (Mounting)
7	12443	1	Body & Cover Assy	34	11448	4	Screw (8-18x1/4)
8	11251	1	Shredder, Stationary	35	13422-P	1	Overload, Protector
9	11260	1	Nut	36	12378	1	Clamp, Overload
10	12445	1	Washer	37	8221	2	Screw (8-32x1/2)
11	12142	1	Washer, Fiber	38	13396	1	Box, Terminal (Incl. code 40)
12	12946	1	Shredder Assy, Rotor	39	12381	1	Screw (8-32x1-1/4)
13	13723	1	End Bell Assy, Upper (Incl. Codes 14 thru 22)	40	12383	1	Grommet, Overload
14	12936	1	Shield	41	12384	1	Bushing
15	1269	6	Screw (8-18x1/2)	42	2466-A	1	Screw, Ground
16	12934-A	1	Seal Assy	43	13709	1	Bearing, Lower
17	12935	1	Sleeve, Spacer	44	13678	1	Spring, Pre-load
18	12860	1	O-Ring	45	13747	1	End Frame, Lower
19	12319	1	Slinger	46	13676	1	Fan
20	12610	1	Bearing Assy, Upper	47	13677	1	Ring, Retaining
21	12326	1	Seal, Water & Oil	48	12490	3	Tube, Spacer
22	11322	3	Key, Woodruff	49	12382-A	3	Bolt, Thru
23	13080	1	Bearing Seal Kit (Incl. Codes 9-10-11 & 14 thru 22)	50	12432	1	Cover, Bottom
24	11444	6	Washer, Lock	51	11757-B	2	Tube Assy, Foot (Optional)
25	11524	6	Screw (1/4-20x1/2)				
26	11459	1	Gasket, Tailpipe				
27	11458	1	Flange, Outlet				