



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	11004	1	Flange, Mounting	29	11456	1	Outlet, Flange
2	11016	1	Gasket, Mounting	30	3130	4	Bolt, Outlet Flange
3	11232	1	Body, Assy, Upper	31	13270	1	Rotor & Shaft Assy (Incl. code 46)
4	1491	6	Screw, Mounting	32	11721	1	Trim, Band
5	11227	1	Pipe, Plug	33	1836A	2	Screw
6	11008	1	Gasket, Shredder	34	13079	1	Stator Assy
7	11725	1	Body & Cover Assy	35	12357	1	Tubing, Insulation
8	11250	1	Shredder, Stationary	36	12384	1	Bushing
9	11255	1	Nut	37	12433A	1	Bracket Assy(Mounting)
10	11256	1	Washer	38	11448	4	Screw
11	12143	1	Washer, Fiber	39	2466A	1	Screw, Ground
12	13273	1	Shredder Assy, Rotor	40	13422AP	1	Overload, Protector
13		1	End Bell Assy, Upper (Incl. Codes 9-11 & 14 - 24)	41	12378	1	Clamp, Overload
14	13266	1	Shield	42	8221	2	Screw, Tapping
15	1269	6	Screw, Tapping	43	13396	1	Box, Terminal Assy (Incl. code 44)
16	13260	1	Seal Assy	44	12383	1	Grommet, Overload
17	13265	1	Sleeve, Spacer	45	12381	1	Screw
18	12860	1	O-Ring	46	12415	1	Bearing, Lower
19	11729	1	Slinger	47	12399	1	Washer, Spring
20	12638	1	Bearing Assy, Upper	48	11672	1	End Frame, Lower
21	11821	1	Support Washer	49	12395	1	Fan
22	11769	1	Oil and Water Retainer	50	12635	1	Ring, Retaining
23	11320	2	Key, Woodruff	51	8039	4	Bolt, Thru
24	11322	1	Key, Woodruff	52	11748	1	Cover, Bottom
25	13281	1	Bearing Seal Kit (Incl. codes 9 - 11 & 14 - 24)	53	8221	3	Screw
26	11444	6	Washer, Lock	54	11757	3	Tube Assy, Foot
27	11524	6	Screw				
28	11457	1	Gasket, Outlet				