



**ORDER BY PART NUMBER, NOT CODE NUMBER**

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	11004	1	Flange, Mounting	28	1461	1	Flange, Tailpipe
2	11016	1	Gasket, Mounting	29	1468	2	Screw (1/4-20x1/2)
3	11020-A	1	Body, Assy, Upper	30	13674-G	1	Rotor & Shaft Assy (Incl. Code 44)
4	1491	6	Screw (1/4-20x3/4)	31	12370	1	Trim, Band
5	11227	1	Pipe, Plug	32	1836-A	2	Screw (8-32x1/2)
6	11006	1	Gasket, Shredder	33	13714-B	1	Stator Assy
7	12442	1	Body & Cover Assy	34	12433-E	1	Bracket Assy (Mounting)
8	11252-A	1	Shredder, Stationary	35	11448	4	Screw (8-18x1/4)
9	11260	1	Nut	36	13422-N	1	Overload, Protector
10	12445	1	Washer	37	12378	1	Clamp, Overload
11	12142	1	Washer, Fiber	38	8221	2	Screw (8-32x1/2)
12	12944	1	Shredder Assy, Rotor	39	13396	1	Box, Terminal (Incl. code 42)
13	13722	1	End Bell Assy, Upper (Incl. Codes 14 thru 22)	40	12381	1	Screw (8-32x1-1/4)
14	12936	1	Shield	41	12383	1	Grommet, Overload
15	1269	6	Screw (8-18x1/2)	42	12384	1	Bushing
16	12934-A	1	Seal Assy	43	2466-A	1	Screw, Ground
17	12935	1	Sleeve, Spacer	44	13709	1	Bearing, Lower
18	12860	1	O-Ring	45	13678	1	Spring, Pre-load
19	12319	1	Slinger	46	13747	1	End Frame, Lower
20	12610	1	Bearing Assy, Upper	47	13676	1	Fan
21	12326	1	Seal, Water & Oil	48	13677	1	Ring, Retaining
22	11322	3	Key, Woodruff	49	11940-A	3	Bolt, Thru
23	13080	1	Bearing Seal Kit (Incl. codes 9-10-11 & 14 thru 22)	50	12490	3	Tube, Spacer
24	11444	3	Washer, Lock	51	12396	1	Cover, Bottom
25	3135	3	Screw (1/4-20x1)	52	11757-B	2	Tube Assy, Foot (Optional)
26	1470	1	Gasket, Tailpipe				
27	5487	1	Tailpipe				